

NOVA CHROME IMPRINTING AT A GLANCE

MATERIAL	TEMP	TIME	NOTES	
CERAMIC,PORCELIAN,GLASS				
PRESSURE				
MUGS 11OZ, 15OZ,	390	MED	4:00	Times may vary with different presses
FROSTED GLASS TANKARD	400	MED	6:00	do not put in water to cool. It will shatter
STAINLESS STEEL TRAVEL MUG	400	MED	2:30	Place upside-down in mug press.
FLUTED CERAMIC STEINS	400	MED	4:30	Place upside-down in mug press.
GERMAN BEER STEINS	400	MED	4:00	Place upside-down in mug press.With green pad.
PORCELIAN BANKS & JARS	400	MED	4:00	Create two transfers and press at the same time
PORCELIAN ORNAMENTS	400	MED	3:00	Let one side cool before doing second side.
GLASS CUTTING BOARDS	400	MED	3:00	Do not mirror image.
CERAMIC TILES 4" x 4"	400	MED	5:00	Add 1 min if using a green transfer pad
CERAMIC TILES 6" x 6"	400	MED	5:00	Add 1 min if using a green transfer pad
CERAMIC TILES 6" x 8"	400	MED	5:00	Add 1 min if using a green transfer pad
POLYSUB MUGS	400	MED	2:15	Put tool in mug before press.Place upside down in press
FABRIC				
BASEBALL CAPS	390	MED	:60	Pre-heat all fabric 5 sec. to remove moisture.
MINI MOUSE PAD COASTERS-	390	MED	:60	Pre-heat all fabric 5 sec. to remove moisture.
MOUSE PADS-	390	MED	:50	Pre-heat all fabric 5 sec. to remove moisture.
TOTE-BAGS	375	MED	:60	Pre-heat all fabric 5 sec. to remove moisture.
POLYESTER PILLOW COVERS	390	MED	1:10	Raise imprinted area with raising pad # PP Pre-heat 5 sec
POLYESTER APRONS	390	MED	:60	Raise imprinted area with raising pad #564 Pre-heat 5 sec
PURSES/WALLETS	390	MED	:60	Hang the velcro strap over the edge of press.
NECKTIES	390	LIGHT	:60	Pre-heat all fabric 5 sec. to remove moisture.
SOFTLINK SQUARES	390	MED	:40	Pre-heat all fabric 5 sec. & use teflon between squares
METAL				
ULTRA-COAT WHITE	360	MED	:55	Place product down in press
ULTRA-COAT GOLD & SILVER	390	MED	:55	Place product down in press
STERLING SILVER JEWELRY	400	MED	:60	Place product face-up
BUSINESS CARD CASE	350	MED	:60	Use pad #556p for press. It will keep the hinges straight
UNISUB JEWELRY ALUMINUM	400	MED	:60	Place product face up
PLASTIC				
UNISUB PLASTIC	400	MED	:60	Place face up in press.
WOOD				
UNISUB WOOD	400	MED	:60	While cooling keep product flat.
THICK WOOD PLAQUES	400	MED	:90	Do not put tape on front or sides of the plaque. Wrap the paper to the back then apply tape
MISCELLANEOUS				
SANDSTONE COASTERS	400	MED	3:00	Use green pad while pressing. Place face up
PUZZLES	400	MED	:60	Use a paper towel under puzzle while pressing.
SUBLIFLEX STICKERS	400	MED	:60	Use a paper towel under subliflex while pressing.

800-788-6682

FAX-925-934-7128

WWW.NOVACHROMEUSA.COM

